


IQOS  
ILUMA


O N E

User Guide


## IQOS ILUMA ONE™



### Charging



Charging Cable



Power Adaptor

IQOS ILUMA™ is compatible only with SMARTCORE STICKS™



For the **full user guide**,  
**Customer Care** and  
**Extended support services**  
for IQOS users, visit

[www.iqos.com/myiqos](http://www.iqos.com/myiqos)


### FEATURES AND SETTINGS

Can be turned on or off  
with the IQOS app\*.

Please register by scanning  
QR code or log in on  
[www.iqos.com/iluma](http://www.iqos.com/iluma)  
and follow the instructions.


\* IQOS app may not be available in  
your country.

# Getting Started



## TURN ON


Press and hold Button for 4 seconds, then release; Status Lights will turn on slowly.



## CHARGE


Before first use, fully charge your IQOS ILUMA ONE™ with Power Adaptor and Charging Cable. (approx. 90 min)

# How to use your IQOS ILUMA ONE™



## OPEN

Slide to open.



## 1. INSERT SMARTCORE STICK™


Insert the SMARTCORE STICK™ to the line on filter with filter facing outside.



## 2. START HEATING

Press Button for at least 1 second until IQOS ILUMA ONE™ vibrates and Status Light(s) pulse(s).


Keep SMARTCORE STICK™ in position during the preheating.



## 3. BEGIN USE

Start using once IQOS ILUMA ONE™ vibrates and Status Light(s) stay fixed.

# How to use your IQOS ILUMA ONE™




## EXPERIENCE COUNTDOWN

During use Status Light(s) indicate the remaining time




## 4. NEARLY COMPLETE

To signal the last 30 seconds or last 2 puffs, IQOS ILUMA ONE™ will vibrate with one Light pulsing white.



## 5. REMOVE SMARTCORE STICK™


Remove used SMARTCORE STICK™ and dispose as per Safety Warnings and Instructions.



## 6. CLOSE


Slide to close.

## Quick Tips



### BATTERY STATUS

Short press Button, Status Lights will turn on to indicate battery level.




### LIGHT BLINKS YELLOW

Battery depleted, need to charge.



### AUTOSTOP


During use, the experience will stop if the SMARTCORE STICK™ is moved, or removed from the device.



### LIGHTS BLINK WHITE TWICE


IQOS ILUMA ONE™ is outside operating temperature range (0°C~40°C).

## Quick Tips



### LIGHT BLINKS RED

Reset IQOS ILUMA ONE™.  
If red light blinking persists,  
contact Customer Care.



### TO RESET

Press Button for 10 seconds  
then release. All Status Lights  
will turn OFF, and turn ON, to  
confirm a RESET.